

2019 CHEVROLET SILVERADO Letter Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974

Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty
CHEVROLET Letters Set	1

Tools Required:

- Rubbing Alcohol
- Clean Towel

“CHEVROLET” Letter Installation

Remove “CHEVROLET” letters from packaging. Check to see if all parts from above kit contents table are included.

1. Clean and dry the vehicle thoroughly.
2. The vehicle surface temperature must be a minimum of 15°C (60°F).
3. Apply rubbing alcohol to the clean towel and wipe down the entire boxed area shown in Figure 1 on the rear letters of the vehicle. This will ensure proper adhesion to the vehicle.

Figure 1



4. Before peeling tape liner, place letters in locations and verify fitment.
5. Peel tape liner and carefully stick letter into indents, as letter will not move once placed. Press letter to promote uniform adhesion. Repeat for all letters.