



Beacon Lighthead - Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974 Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS

Description	Quantity
Beacon Lighthead	1
Bolts and Nuts	3
Foam Gasket	1

Beacon Lighthead Installation

- 1. Verify the kit contents above.
- 2. Clean and dry the vehicle thoroughly in location where the Beacon will be installed.
- 3. After the location is cleaned, test fit the Beacon in that location.
- 4. After identifying the fitment, use the supplied nuts and bolts and secure the Beacon to the vehicle, ensuring that the foam gasket is properly placed behind the Beacon.

Beacon Lighthead Wiring Diagram

Wire Color	Functions
Black	Ground
Red	12V+ for Amber LED's
Blue (if equipped)	12V+ for White LED's
Yellow	Pattern Changing (tap to 12V+)
White	Troubleshoot wire – NOT required / Do not wire.

RJS 7/23/24 BEACON-I

How to Change Color and Pattern

- 1. Determine what colors are desired, then use the table above to determine which wires correspond with each color.
- 2. Connect the corresponding wires for each desired color to 12V+.
- 3. Connect Black wire to ground.
- 4. While the Beacon is on, tap the Yellow wire to 12V+ to get to your desired pattern.
- 5. You're all set, the Beacon will memorize the last pattern that was used and can be turned on/off as you desire.
- NOTE: The Beacon Lighthead is not compatible with the PUTCO Luminix Tap-N-Sync Programable Wireless Remote.

SYNC:

If you are wiring multiple Beacons and you need them to reset to the same pattern/sequence, simply wire all the Beacon yellow wires together and tap/hold 12V+ until the patterns are in sync. You can then select the desired pattern by continuing to tap both yellow wires to 12V+ until the desired pattern is selected.





NOTE: This product is intended for commercial use only. Putco is not responsible or liable for any legal issues resulting in the use of this product beyond its commercial intent.

RJS 7/23/24 BEACON-I