



## 5" Stinger PRO Lighthead - Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974 Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

# KIT CONTENTS

Description	Quantity
5" Stinger PRO Lighthead	1
Self-Tapping Screws	2
Foam Gasket	1

### 5" Stinger PRO Lighthead Installation

- 1. Verify the kit contents above.
- 2. Clean and dry the vehicle thoroughly in location where the Stinger will be installed.
- 3. After the location is cleaned, test fit the Stinger in that location.
- 4. After identifying the fitment, use the supplied self-tapping and secure the Stinger to the vehicle, ensuring that the foam gasket is properly placed behind the Stinger.

#### 5" Stinger PRO Lighthead Wiring Diagram

Wire Color	Functions
Black	Ground
Red	12V+ for Amber LED's
Blue (if equipped)	12V+ for White LED's
Yellow	Pattern Changing (tap to 12V+)
Grey (if equipped)	Dimming (tap to 12V+)
White	Troubleshoot wire – NOT required / Do not wire.

RJS 7/23/24 STINGER12PRO-I

#### **How to Change Color and Pattern**

- 1. Determine what colors are desired, then use the table above to determine which wires correspond with each color.
- 2. Connect the corresponding wires for each desired color to 12V+.
- 3. Connect Black wire to ground.
- 4. While the Stinger is on, tap the Yellow wire to 12V+ to get to your desired pattern.
- 5. You're all set, the Stinger will memorize the last pattern that was used and can be turned on/off as you desire.
- NOTE: The Stinger PRO Lighthead is not compatible with the PUTCO Luminix Tap-N-Sync Programable Wireless Remote.

#### SYNC:

If you are wiring multiple Stingers and you need them to reset to the same pattern/sequence, simply wire all the stinger yellow wires together and tap/hold 12V+ until the patterns are in sync. You can then select the desired pattern by continuing to tap both yellow wires to 12V+ until the desired pattern is selected.





NOTE: This product is intended for commercial use only. Putco is not responsible or liable for any legal issues resulting in the use of this product beyond its commercial intent.

RJS 7/23/24 STINGER12PRO-I